

the specifications

FINDING THE description of the products installation in the Spec Sections - Information from MasterSpec

WHERE IS THE PRODUCTS INSTALLATION DESCRIBED IN THE SPECIFICATIONS?

Description of the product installation related requirements in the specifications is organized as follows:

In DIVISION 01

Section 017300 EXECUTION

- Administrative and procedural requirements governing the execution of the Work, including construction layout, field engineering and surveying, installation of the Work, cutting and patching, coordination, progress cleaning, starting and adjusting, and protection.

WHERE ARE THE PRODUCT INSTALLATION REQUIREMENTS FOUND IN THE SECTIONS ?

The PRODUCT DESCRIPTION in the section contents is organized as follows:

In DIVISIONS 02 to 33

IN PART 1 - GENERAL

- **Pre-Installation Meetings:** These take place typically at the Project Site. The agenda template is available in Rspace.
- **Field Conditions:** These are manufacturer's field condition requirements for the storage and installation of their products.
- **Sustainability Requirements.**

IN PART 2 - PRODUCTS

- **MISCELLANEOUS COORDINATION ISSUES** between components of the work, for example, electrical requirements for motorized products.

IN PART 3 - EXECUTION

- **EXAMINATION** of substrates and other conditions and areas scheduled to receive the product.
- **PREPARATION** Specific provisions required by the product to be installed, such as cleaning, repairing, or other preparations for the installation.
- **ERECTION - INSTALLATION - APPLICATION:** Standards, installation method.
 - Installation tolerances
 - Connections
 - Identification
- **QUALITY CONTROL:** Special Inspections, field testing to verify performance and manufacturer's field services.
- **START-UP SERVICES**
- **ADJUSTING**
- **PROTECTION**
- **MAINTENANCE SERVICE AGREEMENTS**
- **DEMONSTRATION** and Owner's personnel training.

THE END